

EPA Method TO-4A/TO-13A Sampling Instructions



1. Wear gloves whenever handling the PUF cartridges
2. Open the re-sealable bag, and remove the bubble wrapped container
3. Remove the bubble wrap, open the container, and remove the bubble and foil wrapped cartridge
 - a. Retain all packing material for return shipping to the laboratory *
4. Collect sample **
5. Once sampling is complete, wrap the PUF cartridge in original material
 - a. Wrap in foil, place in small bubble bag and place inside the container
 - b. Put the container in the large bubble bag and then into re-sealable bag
6. Close the re-sealable bag
7. Label the re-sealable bag containing both the PUF and the filter
8. Fill out the Chain-of-Custody
9. Ship back to the laboratory on ice

* Pack the sampling cartridge in the reserved packing material as the client is responsible for any damage, each cartridge has a value of \$200.

**For specific instructions regarding the operation of high volume samplers, please refer to your manufacturer's guidelines or project plan.

Calscience does not provide rental or support for this equipment.

If at any point you have questions, please call your Calscience Project Manager at 714.895.5494

The difference is service